

H100

Accessories Guide



STD. Spec.

Adapter



PWR-H100-5V2A-CN

H100 adapter(CH), WH, I/P 100-240V, O/P: 5V2A, use with DC-H100-TypeC cable.



PWR-H100-5V2A-EU

H100 adapter(EU), I/P 100-240V, O/P: 5V2A, use with DC-H100-TypeC cable.



PWR-H100-5V2A-UK

H100 adapter(UK), I/P 100-240V, O/P: 5V2A, use with DC-H100-TypeC cable.



PWR-H100-5V2A-US

H100 adapter(IND), I/P 100-240V, O/P: 5V2A, use with DC-H100-TypeC cable.

USB Cable



DC-H100-TypeC

1.0 meter Type-C cable


Lanyard



SG-H100-LYD-WT

H100 lanyard, White

Sim Tray Ejector



SIM-TRAY-EJECTOR

Sim tray ejector

Optional

Charging Cradle



CRD-H100-SCC

H100 charging cradle can charge one device, use with DC-H100-TypeC cable.

Charging Rack



RACK-CC-8

Each unit of the charging rack has various levels and can charge up to 8 devices at a time, use with charging cradle. The quadrate alloy cradle is elegant and rugged. You can have tens of devices charged on several charging racks. It saves space and time, ideal for indoor use. Applicable models: C6000, H100, C70, C71, C72 (without UHF module and pistol grip).