

# R2

Bluetooth RFID Reader

## Accessories



### STD. Spec.

#### Adapter



PWR-R2-5V2A-CN



PWR-R2-5V2A-EU



PWR-R2-5V2A-UK



PWR-R2-5V2A-US

Adapter(CN/EU/UK/US), I/P: 100-240V, O/P: 5V2A, use with DC-R2/R6-USB cable

#### USB Cable



**DC-BK-MicroUSB**  
1.0 meter Type-C cable

#### Battery



**BTRY-R2-52MA**  
5200mAh Li-ion battery

### Optional

#### Charging Cradles & Adapters



**CRD-R2-MBC**  
Charging Cradle for battery, up to 2 slots, use with DCPWR-12V2A-XX



**DCPWR-12V2A-XX**  
CN UK EU US

#### R2 Extension Pole



**RB-R2-ER**

